
Let's get together.

The Bed + Headboard \rightarrow

Unsecured pieces can tip over during assembly. For safety, follow assembly instructions by holding pieces in place until fully secured. Avoid balancing pieces. Do not bend over around unsecured pieces and keep out of the way of children.




Lay out the pieces where you'd like The Bed.


Arrange Long Rails (sides) with "U" joints facing out and Short Rails (wall and foot) with "U" joints facing in. Step into the center of the frame.

Side


Keep the Slats on the sideline for now.

Set aside two of the Short Legs for future optionality.







Foot of The Bed




Begin with the Left Long Leg to start the assembly. The Long Legs should be facing you in this direction as you assemble The Bed.




moving on to the next step.



A. While holding Long Rail and Long Leg in place, insert Short Rail into the left Long Leg, on top of Long rail with "U" joint facing down.



B. Angle Long Leg and Long Rail towards Short Rail for smoothest fit.



C. Push the Short Rail down fully.


Rest Short Rail on floor for a moment.

Pick up the Right Long Leg. Insert Long Rail with Screws Side facing inward, "U" joint facing up.


Ten

Hold pieces in place while moving on to the next step.


Right Long Leg



A. Lift the Short Rail.




B. Insert Short Rail into the right Long Leg.




C. Push the Short Rail down fully.





Place the remaining Short Rail into the Short Legs, "U" joint facing down, and press it down fully.




A. Screw the Center Leg into the Center Rail.

B. Place the Center Rail into the horseshoes on the inside of the frame.


C-D. Use the Long Screws to secure the Short Rail into the Center Rail. Tighten by hand. Long Screws

D





View from back

A-B. Use the Short Screws behind the Long Legs to secure Bottom Board on each side. Tighten by hand.




Place the Top Board on top of the Bottom Board, lining up the Pins with the Pin Holes. Ensure Top Board's curvature is facing the inside of the frame.





A-B. Use the remaining two Short Screws behind the Long Legs to secure the Top Board in place. Tighten by hand.



A. Lay rolled Slats down at the head of The Bed. Place the first slat between the Short Rail and Slat Stop to hold in place.

B. Roll down to the foot of The Bed and place the last slat between the Short Rail and Slat Stop.

A

В


Slat Stop

Slats should be tight and secured.

A. The Center Leg doubles as a leveler. Adjust up and down, as needed.

B. Place your mattress on top of The Bed. The added weight will stabilize the frame.

And you're all set.



Enjoy Bed Time.

Light a candle, play some jams, pour yourself a refreshment. Share your favorite Bed Times with us on Instagram @thuma.co for a chance to be featured.

thuma.co | @thuma.co | #thuma #forBedTime