

Let's get together.

Upgrade to The Headboard →

Unsecured pieces can tip over during assembly. For safety, follow assembly instructions by holding pieces in place until fully secured. Avoid balancing pieces. Do not bend over around unsecured pieces and keep out of the way of children.

Part One


Disassembly

Like the initial assembly, this will only take a few minutes and make attaching The Headboard much simpler.

Step 1


Disassemble The Bed.

A-B. Set The PillowBoard and The Mattress aside.



Step 2


Roll the Slats up and set aside.



Step 3


A-B. Remove Long Screws.

C. Then remove Center Rail.
You can keep The Center
Leg attached.




Step 4

Remove the Short Rail on the front first.



Step 5


A-B. Carefully remove one leg at a time. Hold the Long Rail while removing leg. Gently rest Long Rails on the floor.



Step 6

A. Remove second Short Rail. Ensure Long Rail and Legs do not fall to floor.

B-C. Then Remove Long Rails from the Legs.




Part Two

Reassembly


Better Bed Time
is only moments away.

The Pieces

Top Board x1



Pin




Pin Hole


Bottom Board x1



Long Rail x2



Screws Side



Slat Stop

Short Rail x2



Center Rail x1



Short Leg x4



Long Leg x2



Center Leg x1




Short Screw x4




Long Screw x2




Slats x1



Rounded Corner



"U" Joint



Horseshoe



Step 1

Lay out the pieces where you'd like The Bed.


Arrange Long Rails (sides) with "U" joints facing out and Short Rails (wall and foot) with "U" joints facing in. Step into the center of the frame.

Keep the Slats on the sideline for now.


Set aside two of the Short Legs for future optionality.



Step 2




Left Long Leg



Right Long Leg


Begin with the Left Long Leg to start the assembly.
The Long Legs should be facing you in this direction as you assemble The Bed.

Step 3




Insert Long Rail with Screws Side facing inward, "U" joint facing up.

View from the left




Insert Long Rail fully.




Hold pieces in place while moving on to the next step.


Step 4



A. While holding Long Rail and Long Leg in place, insert Short Rail into the left Long Leg, on top of Long rail with "U" joint facing down.




B. Angle Long Leg and Long Rail towards Short Rail for smoothest fit.




C. Push the Short Rail down fully.

Rest Short Rail on floor for a moment.




Step 5

Pick up the Right Long Leg.
Insert Long Rail with Screws Side
facing inward, "U" joint facing up.




Right Long Leg




Hold pieces in place while
moving on to the next step.


Step 6




A. Lift the Short Rail.



B. Insert Short Rail into the right Long Leg.




C. Push the Short Rail down fully.



Step 7


A. Move towards the foot of The Bed.
Place Short Leg under Long Rail.

B. Repeat for the other side.



Step 8


Place the remaining Short Rail into the Short Legs, "U" joint facing down, and press it down fully.



Step 9

A. Screw the Center Leg into the Center Rail.

B. Place the Center Rail into the horseshoes on the inside of the frame.




C-D. Use the Long Screws to secure the Short Rail into the Center Rail. Tighten by hand.



Long Screws

Step 10

A-B. Place the Bottom Board between the Long Legs. The Pin Holes should face up with the board's curvature facing the inside of the frame.





View from back




Step 11

A-B. Use the Short Screws behind the Long Legs to secure Bottom Board on each side. Tighten by hand.




Step 12

Place the Top Board on top of the Bottom Board, lining up the Pins with the Pin Holes. Ensure Top Board's curvature is facing the inside of the frame.





View from side.



Step 13

A-B. Use the remaining two Short Screws behind the Long Legs to secure the Top Board in place. Tighten by hand.




Step 14

A. Lay rolled Slats down at the head of The Bed. Place the first slat between the Short Rail and Slat Stop to hold in place.

B. Roll down to the foot of The Bed and place the last slat between the Short Rail and Slat Stop.

Slats should be tight and secured.




Step 15

A. The Center Leg doubles as a leveler.
Adjust up and down, as needed.

B. Place your mattress on top of The Bed.
The added weight will stabilize the frame.

And you're all set.



Enjoy Bed Time.

Light a candle, play some jams, pour yourself a refreshment.
Share your favorite Bed Times with us on Instagram @thuma.co
for a chance to be featured.

thuma.co | @thuma.co | #thuma #forBedTime